V4
FINAL
FOR PRINT

NS-R2111_14-1141_QSG_V4_EN.ai 1 10/7/2014 3:05:09 PM

Flat size (W×H): 297 × 210 mm.
Final folded size: 99 × 210 mm.

INSIGNIA™

Quick Setup Guide | NS-R2111
6 ½" 2-Way Outdoor Rock Speakers

Congratulations on your purchase of a high-quality Insignia product. Your NS-R2111 represents the state of the art in outdoor speaker design and is designed for reliable and trouble-free performance.

PACKAGE CONTENTS

- Rock speakers (2)
- 50 feet (15.2 m) of outdoor speaker wire
- Twisted wire connectors (4)
- *Quick Setup Guide*

Tools you will need:

- A small spade or shovel
- Measuring tape
- Wire cutters
- Wire strippers

Before using your new product, please read these instructions to prevent any damage.

SAFETY INFORMATION

Although your new rock speakers are designed to withstand outdoor conditions, you can do these things to prolong the life of your speakers:

- Keep dirt and leaves from covering the speaker grille. If dirt accumulates on the grille, rinse it off with water.
- Avoid facing the speakers directly at sprinklers.
- Chemicals commonly used in the back yard may damage the rubber parts of the speakers. Avoid spraying yard care chemicals onto the speakers.

SETTING UP YOUR SPEAKERS

Planning speaker locations

Your rock speakers feature a wide angle of coverage. A few speakers will cover a large area with sound.

When designing your outdoor system:

- It's better to have more speakers playing at lower volumes than fewer speakers playing at high volumes.
- Place the speakers as close to the listening area as possible.
- Make sure that you can easily run wire to each of the speaker locations.

Connecting the speakers

1. With your tape measure, measure out lengths of speaker wire required to connect each speaker.
2. Cut the off the excess wire with a wire cutter making sure to leave enough extra wire to make connections. Use the wire strippers to remove a small amount of insulation from the end of the wire.
3. With the small spade or shovel, dig a five-inch deep trench from the amplifier to each speaker location for the speaker wire.
4. Connect the outdoor speaker wire to the wire from the bottom of the speaker. Make sure the polarity of the speaker wire connections is correct by connecting the red wires together and the black wires together.
   Note: The speaker wire can be run beneath the speaker into the ground or through the notch on the bottom of the speaker to the side.
5. Run the wire through the trench to the amplifier.
6. Connect the other end of the outdoor speaker wires to your amplifier. Connect the red wires to the red (+) speaker terminals (R and L) on the amplifier and the black wires to the black (-) speaker terminals (R and L) on the amplifier.
7. Turn your amplifier on and test the system with your favorite music. If the speakers are operating properly, fill in the wire trench.
   Caution: Make sure that all connections are secure. A poor connection can lead to corrosion and loss of performance. For best results, crimp or solder the wires together, then cover with the twisted wire connectors provided.

SPECIFICATIONS

Speaker type	Weather-resistant rock speaker
Tweeter	0.5 in. (13 mm) coaxial tweeter with poly-ether imide (pei) diaphragm
Woofer	6.5 in. (165 mm) driver with polypropylene cone and rubber surround
Impedance	8 ohm
Sensitivity	86 +/-2 dB
Frequency response	120 Hz - 20 kHz
Power recommendation	5 - 50 Watt RMS
Dimensions	9.5 × 13.3 × 7.9 in. (24.1 × 33.8 × 20 cm)
Weight	7.8 lbs. (3.6 kg) (per piece)

NS-R2111_14-1141_QSG_V4_EN.ai 2 10/7/2014 3:05:18 PM

ONE-YEAR LIMITED WARRANTY

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded or Future Shop branded retail store or online at www.bestbuy.com, www.bestbuy.ca, or www.futureshop.ca and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy or Future Shop retail store location, please take your original receipt and the Product to any Best Buy or Future Shop store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. If you purchased the Product from a Best Buy or Future Shop online web site (www.bestbuy.com, www.bestbuy.ca, or www.futureshop.ca), mail your original receipt and the Product to the address listed on the web site. Make sure that you put the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain warranty service, in the United States call 1-888-BESTBUY, Canada call 1-866-BESTBUY for Future Shop call 1-800-663-2275. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy or Future Shop branded retail stores or websites to the original purchaser of the product in the county where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse
- Negligence
- Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.
- Modification of any part of the Product, including the antenna
- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply
- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold "as is" or "with all faults"
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- Loss or Theft of this product or any part of the product
- Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)
- Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.
Registered in some countries.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2014 Best Buy. All rights reserved.
Made in China